

If Interactive Talking Turtle is not working, try resetting Interactive Talking Turtle. **To Reset:** Slide the switch to "OFF", then slide the switch to the "ON" mode. If Interactive Talking Turtle is still not working, try replacing the batteries.

## To change batteries:

- · Unscrew battery cap.
- Take out old batteries and replace with 3 new AAA batteries.
- · Replace battery cap.

## **Battery Instructions:**

- · Non-rechargeable batteries are not to be recharged.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- · Batteries are to be inserted with the correct polarity.
- · Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- · Batteries are to be removed from the toys when not in use.
- · Batteries should only be replaced by an adult.
- · Do not dispose of batteries in fire.
- Do not use rechargeable batteries.

Batteries are included for demonstration purposes only and may need to be replaced by the consumer. Adult supervision is required to replace batteries.

**Batteries Regulation:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Under the environment with severe electrostatic discharge, the product may malfunction and requires user reset.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.



ON OFF

## INTERACTIVE TALKING MIKE

WARNING: CHOKING HAZARD- Small parts. Not for Children under 3 years.

Press button to activate sounds.

When interacting with other "Interactive Talking Turtles" make sure belt sensors are facing towards each other. Press button on each Turtle to awake from sleep mode... If Turtles are not interacting, please press button on each Turtle to awake from sleep mode and or adjust the position of the Turtle so belt sensors are angled toward each other.

OR

Best sensor alignment:



OR

Ages 4 and up Asst. #91380 Item #91383

©2014 Viacom International Inc. All Rights Reserved. TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom International Inc. ©2014 Viacom Overseas Holdings C.V. All Rights Reserved. TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom Overseas Holdings C.V. ©2014 Playmates. Playmates International Company Ltd. 23/F, The Toy House, 100 Canton Road, TST, Kowloon, Hong Kong. PRINTED IN CHINA.